


# Fire Alarm Panel FPA-5000/1200 (BOSCH) to VAS-CU connecting diagram via FLM-420-RLV8-S and FLM-420-I2-E(W)



To connect VAS-CU to Fire Alarm Panel FPA-5000/1200 (BOSCH) should be used relay modules set up directly in Fire Alarm Panels (RML 008) or connected into the addressable line LSNi (FLM-420-RLV1-D and FLM-420-RLV8-S). For monitoring the status of VAS using common failure signal form VAS-CU output. It comes to interface module input FLM-420-I2-E(W). It evaluates condition of VAS and sends the information to addressable line LSNi. Setting up the addresses of relay modules and input module performs with switches, located on modules itself or using Fire Alarm Panels FPA-5000/1200 software. Relay Modules work algorithm programming performs with Fire Alarm Panels FPA-5000/1200 software.